MODEL 261 series

Alternating Relays

- Solid-state Reliability
- Heavy-duty Contact Rating
- Optional Load 1-Load 2 Toggle
- UL Recognized; CSA Certified




The Model 261 series Alternating Relay is designed for duplex pumping systems where it is desirable to equalize pump run time. The solid state alternating circuit drives an internal electromechanical relay. A continuous power source and control switch are required.

The control switch (float, pressure or other isolated contact) is connected between the L1 terminal and the control terminal. Each time the control switch is opened the output contacts will change states. Indicator lights on the case show the internal relay status.

On the optional toggle switch versions, the toggle switch is set to the NORMAL position. Setting the switch to Load 1 or Load 2 will lock the relay in position, preventing alternation.

DIMENSIONS - 261S or 261DX



*add 3/4" (0.75) for toggle clearance on applicable models




SPECIFICATIONS

MODEL	261 x (T) - xxx				
Supply Voltage	12V AC/DC	24V AC/DC	120V AC/ DC	240V AC/DC	
Voltage Range	10 - 14V	20 - 28V	90 - 130V	180 - 250V	
Max Voltage	15V	30V	140V	260V	
Supply Current	0.1A	0.05A	0.01A	0.01A	
Control Current	0.001 amp				
Operating Duty	Continuous				
Min. Cycle Time	100 msec				
Contacts	10A at 120VAC resistive				
Expected Relay Life	Mech: 10 million operations Elec: 100,000 operations at rated load				
Operating Temp	240V models: - 40° to +131° F All other models: - 40° to +140° F				
Humidity Tolerance	0 - 97% w/o condensation				
Mounting	261D: 11-pin socket * 261S or 261DX: 8-pin socket **				
Enclosure Material	ABS plastic				
Weight	4.3 oz.				
Agency Approvals	UL Recognized and CSA Certified				

*order 11-pin socket # 51X016 **order 8-pin socket # 51X120

ORDERING INFORMATION						
MODEL	RELAY POLES	TOGGLE	SUPPLY VOLTAGE			
261	S=single pole	Т	12 V AC/DC			
	D =double pole		24 V AC/DC			
	DX =dbl pole x-wired		120 V AC/DC			
			240 V AC/DC			
example: 261-DX-120 orders a 120V AC/DC; double-pole, x-wired Alternating Relay w/o the toggle option.						







MODEL 261 Alternating Relays

READ ALL INSTRUCTIONS BEFORE INSTALLING, OPERATING OR SERVICING THIS DEVICE. KEEP THIS DATA SHEET FOR FUTURE REFERENCE.

GENERAL SAFETY

POTENTIALLY HAZARDOUS VOLTAGES ARE PRESENT AT THE TERMINALS OF THE MODEL 261. ALL ELECTRICAL POWER SHOULD BE REMOVED WHEN CONNECTING OR DISCONNECTING WIRING. THIS DEVICE SHOULD BE INSTALLED AND SERVICED BY QUALIFIED PERSONNEL.

Installation Instructions


INSTALLATION


Connect wiring to the socket as indicated in the following examples.

The Model 261 series Alternating Relays are extremely versatile and can be used in many other configurations besides those shown. Any type of switch (float, pressure, etc.) can be used as the control switch; however, it must be connected as shown (from L1 to the control input) or the alternator will not function properly.

On Toggle Versions: For normal operation (alternating loads) set the toggle switch on the top of the case to the "normal" position. Setting the toggle switch to either "1" or "2" will lock the alternator in that position.


TYPICAL APPLICATION: 261D





TYPICAL APPLICATION: 261S


NOTE: All drawings shown with no power applied.




TROUBLESHOOTING

Should the Model 261 fail to operate properly, check to see that voltage level and connections are correct and securely attached to equipment. Should problems persist, contact the factory at 800-862-2875 for assistance.

TYPICAL APPLICATION: 261DX





WARRANTY

The Model 261 Alternating Relay is warranted to be free from defects in materials and workmanship, and is covered by our exclusive 5-year Unconditional If the this device fails to operate, for any Warranty. reason, we will repair or replace it free, for five years from the date of purchase. Contact the Time Mark Sales department, Monday through Friday; 8 a.m. to 5 p.m., CST, for further details.

